















No.	Part	Pcs
A		1
B		1
C		2
D		4
E		2
F		4
G		2
H		2
I		1
J		8
K		4
L		2
M		8
N		1

## Aufbauanleitung - 676461 - Garberobenständer

1. Verbinden Sie die Seitenteile C mit den Stangen D (4x). Nutzen Sie hierfür die Schrauben M (8x) und den Imbusschlüssel (N). Montieren Sie nun die Rollen G + H. Nutzen Sie hierfür das Werkzeug I sowie die Teile K (4x). Die Rollen H verfügen über eine Feststellbremse, Sie können diese Wahlweise vorne oder hinten montieren.

2. Verbinden Sie nun den Unterbau mit dem Teil B. Nutzen Sie hierfür die Schrauben L.

Anschließend können Sie das Teil A montieren

3. Nun folgt das Einsetzen der Böden E (2x) wie in Abb. 3 dargestellt.

## Assembly instructions - 676461 - Coat rack

1. Connect side panels C to rods D (4x). Use the screws M (8x) and the Allen key (N) for this purpose. Now assemble the rollers G + H. Use the tool I as well as the parts K (4x). The H-wheels are equipped with a parking brake, you can mount them either in front or in the back.

2. Now connect the substructure to the part B. Use the screws L. Then you can mount the part A.

3. Now, insert the trays E (2x) as shown in Fig. 3.

